Mini & Graphite NVR

Motion detection

domar.com

Enabling motion detection on IP camera

1. Open camera's website.
    a. Check what is IP address of a camera using IPCSearcher (download link).



    b. For wireless IP cameras, use SearchTool (download link) software instead.



c. Open Internet Explorer web browser.
d. Put camera's IP address in address bar, press Enter.



e. Download and run camera plugin.



f. Restart Internet Explorer and access camera web page again.
g. Click **'Allow'** when Internet Explorer ask you if you want to run camera's plugin.



2. Log in, default username and password are: **admin** / **admin**.

3. Enabling motion detection - IP camera (new web interface).
    a. Go to **‘Configuration’**, then **‘Events’**.
    b. Enable motion detection.
    c. Select detection area - either drag your mouse over camera’s picture to select area yourself or click **‘Select All’** button.
    d. Choose **‘Sensitivity’** (0 - lowest, 10 - highest).
    e. **‘Save’** settings.



    f. Additionally you can choose when motion detection will be active by clicking **‘Arming Schedule’** tab - click on a time bar to change it.

4. Enabling motion detection - IP camera (old web interface).
    a. Go to **‘Alarm’**.
    b. Enable alarm and motion detection - tick ‘Enable Alarm’ and ‘Motion detection’ boxes.
    c. Save settings by pressing **‘OK’** button.



    d. Go to **‘Motion’**.
    e. Select detection area - either drag your mouse over camera’s picture to select area yourself or click **‘Select All’** button.
    f. Choose **‘Sensitivity’** (0 - lowest, 10 - highest).
    g. Save settings by pressing **‘OK’** button.



5. Enabling motion detection - wireless IP camera.
    a. Go to PC View, click **'Sign In'**.



    b. Download and run ActiveX plugin.



c. Add camera's webpage to Internet Explorer's Compatibility View'.



d. Click **'Allow'** when Internet Explorer ask you if you want to run camera's plugin.



e. Go to **'Settings'**.



f. From menu choose **‘Alarm’**
g. and then **‘Motion Detection’**.



h. Scroll down and enable **‘Window1’**.
i. Choose **‘Sensitivity’** (0 - lowest, 100 - highest).
j. Change size of detection area - click and drag bottom right corner of green square.
k. Save settings by pressing **‘Apply’** button.
l. Additionally you can choose when motion detection will be active by choosing **‘Schedule’** in menu - click on a timeline to activate (green) / deactivate (white) detection for choosen hour.

Enabling motion detection on the NVR

1. Go to main menu (right click on screen, choose **‘Main menu’**).
2. Click on **‘Event’**.



a. Choose channel (camera number) which you want to detect motion.
b. Choose sensitivity (0 - lowest, 10 - highest).
   Note: camera’s motion detection settings takes priority over NVR’s.
c. Enable motion detection (orange tick - enabled, grey - disabled).
d. (Optional) enable buzzer and decide how long alarm sound should be played.
e. Enable recording on motion and set post-recording time.
f. Save settings by clicking **’Confirm’**.

3. Change recording schedule.
    a. Go to **‘Storage’** (from Main menu).
    b. Choose camera **‘Channel’** (number).
    c. Click gear icon for choosen day.



    d. Enable motion detection recordings by ticking **‘Motion’** and (optional) disable continuous recordings - **‘Record’**.

Record Schedule
Current Set Week : Sunday
Schedule 1
00 : 00 - 24 : 00
Record
Motion
Schedule 2
00 : 00 - 00 : 00
Record
Motion
Schedule 3
00 : 00 - 00 : 00
Record
Motion
Schedule 4
00 : 00 - 00 : 00
Record
Motion
Schedule 5
00 : 00 - 00 : 00
Record
Motion
Schedule 6
00 : 00 - 00 : 00
Record
Motion
Use to:
ALL
Sun.
Mon.
Tue.
Wed.
Thu.
Fri.
Sat.
Save
Cancel

Enabling motion detection on the NVR from computer

1. Open NVR's website.
    a. Check what is IP address of a NVR using IPCSearcher (download link).



Or check is on the NVR by going to **Main menu -> Network**.

    b. Open Internet Explorer web browser.
    c. Put NVR's IP address in address bar, press Enter.



d. Download and run NVR's plugin.



e. Restart Internet Explorer and access camera web page again.

f. Click **'Allow'** when Internet Explorer ask you if you want to run OCX plugin.

2. Log in, default username and password are: **admin** / **12345**.
3. Go to **Basic Setup -> Channel -> Motion detection**.



a. Choose **'Channel'** (camera number) which you want to detect motion.

b. Enable motion detection - tick **'Switch Linkage'** box.
   Choose sensitivity (0 - lowest, 10 - highest).
   Note: camera's motion detection settings takes priority over NVR's.
c. (Optional) enable buzzer - **'Buzzer On'** and decide how long alarm sound should be played.
d. Enable recording on motion - **'Record Channel'** and set post-recording time - **'Record Time'**.
e. Save settings by clicking **'Save'**.

4. Change recording schedule.
   a. Go to **Basic Setup -> Channel -> Motion detection**.
   b. Choose **'Channel'** (camera number) which you want to detect motion.
   c. Click gear icon for choosen day.



d. Enable motion detection recordings by ticking **'Motion'** and (optional) disable continuous recordings - **'Record'**.

Logout
Playback
Basic Setup
LiveVideo
Schedule Setup
Save
Return
Week
Sun
Schedule1
Schedule2
Schedule3
Schedule4
Schedule5
Schedule6
Normal
Motion
Copy All
Select All
Sun
Mon
Tue
Wed
Thu
Fri
Sat
System
Channel
Record
Maintain